



GoPro HERO5 Black

This small and versatile action camera will record ultra HD 4K video to your MicroSD card. It is durable & waterproof (up to 33 feet), with the ability to take 12MP still photos and a built-in touch display for setting up and reviewing your shots.

Kit contains:

- GoPro Hero 5 Black camera
- These instructions
- CD with GoPro Hero 5 manuals
- Plastic CD case
- The Mounting frame (HERO5 Black), including thumb screw & mounting buckle
- Rechargeable battery (HERO5 Black)
- Curved adhesive mount
- Flat adhesive mount
- Large flat adhesive mount
- USB cable
- Carrying case

Machine and user manual information:

- The brand/model is the GoPro Hero5 Black.
- Both the User Manual and the Let's Get Started Manual are on the CD contained in this kit.
- The User's Manual and the Let's Get Started Manual are also available online:
<http://urbanafreelibrary.org/books-more/productivity-collection>.

What you will need besides the unit and cables borrowed from the library:

- Required – 1 MicroSD card
- Optional – HDMI cable, if you want to play recordings on your TV
- Optional – a smart phone or tablet for GoPro app, for editing
- Optional -- Sturdy Velcro® or other removable fastener product, to use on the mounts that come with this kit


Set up and power on the GoPro:

- Remove the GoPro from mounting frame by releasing the latch at the top.
- To open the mounting frame, you need to pop open the latch. Holding the camera pointing forward, pull the front edge of latch up and back towards you. Don't be afraid to use a little force as the latch will be snug in the mount. The latch is on a hinge. With the latch unlocked and the door open, turn the front of the camera towards you and simply push the camera out of the mount.

MOUNTING


Securing the Camera in The Frame

1. Open the latch.
2. Slide the camera into the frame. The bottom front of The Frame has a raised edge. Be sure the front of the camera sits flush against it.
3. Close the door.
4. Lock the latch.



- Open the battery door and insert the battery and your microSD card into the card slot as shown.
- Plug the GoPro into a wall charger or computer via the provided USB cable.
- After charging the battery, power on the camera and take the tour by using the touch display.


SET UP



Open the battery door.


NOTICE

The camera is not waterproof when the doors are open.




Insert a microSD™ card (sold separately) + battery.


POWER ON



Power on the camera.



Open the side door.



Charge the battery.



Take the camera tour.


Operating the camera:

CAPTURE VIDEO + PHOTOS


Select the desired camera mode with the touch display or Mode button.



Press the Shutter button to start and stop recording.



VOICE CONTROL



1. Swipe down, then tap Preferences > On Camera Voice Control.
2. Select a language. For English and Spanish, be sure to choose your dialect.
3. Tap On.
4. Say a command:
 - GoPro start recording
 - GoPro stop recording
 - GoPro take a photo

To see all of the commands, go to Preferences > List of Commands.

Use the included camera mounts for flexibility in filming.

While you can setup and edit on the GoPro Hero5 Black camera itself, download the GoPro mobile or desktop apps, for full editing control.

CAMERA MOUNTING

Curved Adhesive Mount

Apply an adhesive mount to a clean surface at room temperature.

Insert the camera into the mounting frame.

Click the mounting buckle into the adhesive mount.

TIP
After use in sand, dirt or salt water, rinse the camera in fresh water.

APPS

Capture and create stunning videos. Our mobile and desktop apps make it easy.



CAPTURE
Live preview, playback + full camera control.



QUIK™
Awesome edits made easy.



QUIK | DESKTOP
Import and enjoy your footage, and create awesome videos with just a few clicks.

▶ Download at gopro.com/apps

UPDATE YOUR GOPRO
Connect to the Capture app or Quik desktop app to check for updates and get the latest camera features.

Caution: If you utilize the mounts that come with this kit, use sturdy Velcro® or another removable fastener product. It is your responsibility to make sure you attach the GoPro securely to the mount while in use, to avoid damage to the camera.



The Urbana Free Library

210 W. Green Street • Urbana, Illinois 61801 • 217-367-4405 • urbanafreelibrary.org

July 2017